## **Ford Focus - Fix points**





You will need a 'flat head' and a 'Philips head' screwdriver.



Use the 'flat head' screwdriver and turn the plastic cover screw 90 degrees.



This will release the cover, lift 45 degrees up and slide out of the housing.



Each of the four channels are filled with a form of 'putty', the fix point is located in the centre of the channel.



Using your 'Flat head' screwdiver, begin to remove the 'putty'.

Take your time.



You don't need to remove all the putty, just enough to access the fix point.



Once you have removed the covering layer of putty you will discover the plastic fix point retaining screw.



Using your 'philips head' screwdriver, remove the plastic retaining screw.



This will only unscrew to a point Using your fingers remove the screw.



Keep hold of this, we suggest placing all four of these in a small grip seal bag.



You can now fit your roofbars.