# **K334 FITTING INSTRUCTIONS**



These fitting instructions contain information specific for your vehicle. They should be read in conjunction with your crossbar instructions.

#### Kit contains:

4 x Clamps

4 x Stepped Rubber Pads

Contact your Prorack Dealer if any parts are missing.

### Items you may require that are not included:

1 x Tape Measure

#### Instructions

Replace the Standard Rubber Pads that come with the Crossbar with the Stepped Pads supplied in this fitting kit. Clamps directly to edge of roof under the doors, clamp pin locates in hole on vehicle body on front clamps.

## **Crossbar Spacing**

Pictured are Whispbar Flush Bars. Positioning also applicable for Whispbar Through Bars.

37cm

68cm

31cm

Front





