## How to pack a bike in a box

In the examples below of how best to pack your bike, we have used the B&W International Bike Case. However, please be aware the various steps may vary depending on what box you have.



Remove your wheels:

Start by removing both wheels from your bicycle, there is no need to deflate your tyres.



Mount your bike to the aluminium frame:

Remove the skewers from your bicycle and insert the provided skewers through your forks, into the aluminium tubing so that your bike is held in place.



Insert bike into box:

Place the aluminium frame with mounted bicycle into the padded bike box.



## Remove aluminium frame:

Remove the aluminium frame from within the case and position on a flat surface, with both centre struts pointing upwards.



Mounting your wheels:

Mount both wheels to the upright struts of the aluminium frame, with one wheel at either side of the bicycle.



## Close and lock box:

Close and lock the bike box by simply pushing down the 4 flush fitting locks.