



GB Fitting Instruction for Accessory




x 4



x 4



x 4



x 4



MAX kgs



W/P WHD

MAX kgs



W/P WHD

Lexus

LX470 , 5dr SUV Apr 98-Jul 07 AU 75 100

Suzuki

SX4 , 5dr Hatch 06-+ ZA 40 40

SX4 , 5dr Hatch Mar 07-+ AU 40 40

SX4 Sportback, 5dr Hatch 07-+ US 40 40

Toyota

Land Cruiser 100 Series, 5dr SUV 98- 07 US 75 100

Land Cruiser 100 Series, 5dr SUV 98- 07 EU 75 100

Land Cruiser 100 Series, 5dr SUV Apr 98- Oct 07 NZ 75 100

Land Cruiser 200 Series, 5dr SUV 07-+ EU 75 100

Land Cruiser 200 Series, 5dr SUV Nov 07- + NZ 75 100

Land Cruiser Prado , 5dr SUV Mar 03-Nov 09 NZ 75 100

Land Cruiser Prado GX, 5dr SUV Dec 09-+ NZ 75 100

Rav 4 , 3dr SUV 00- 05 ZA 75 80

Rav 4 , 3dr SUV 94- 00 EU 75 75

Rav 4 , 3dr SUV 94- 99 ZA 75 75

Rav 4 , 3dr SUV Jun 94-May 00 AU 75 75

Rav 4 , 5dr SUV 00- 04 EU 75 80

Rav 4 , 5dr SUV 94- 00 EU 75 80

Rav 4 , 5dr SUV Dec 94-May 00 NZ 75 80

Rav 4 , 5dr SUV Jun 00-Jan 06 NZ 75 80

Rav 4 20 Series, 5dr SUV Jun 00-Jan 06 AU 75 80

LX470 , 5dr SUV May 98-Oct 07

NZ 75 100

SX4 , 5dr Hatch 06-+

EU 40 40

SX4 , 5dr Hatch Mar 07-+

NZ 40 40

Land Cruiser 100 Series, 5dr SUV 98- 07 ZA 75 100

Land Cruiser 100 Series, 5dr SUV Apr 98- Jun 07 AU 75 100

Land Cruiser 200 Series, 5dr SUV 07-+ US 75 100

Land Cruiser 200 Series, 5dr SUV Aug 07- + AU 75 100

Land Cruiser Prado , 5dr SUV 03- 09 EU 75 100

Land Cruiser Prado 120 Series, 5dr SUV Mar 03-Oct 09 AU 75 100

Land Cruiser Prado GX, 5dr SUV Nov 09-+ AU 75 100

Rav 4 , 3dr SUV 00- 06 EU 75 80

Rav 4 , 3dr SUV 94- 00 US 75 75

Rav 4 , 3dr SUV Jun 00-Jan 06 NZ 75 80

Rav 4 , 3dr SUV Jun 94-May 00 NZ 75 75

Rav 4 , 5dr SUV 00- 06 ZA 75 80

Rav 4 , 5dr SUV 94- 99 ZA 75 80

Rav 4 , 5dr SUV Jul 95-May 00 AU 75 80

Rav 4 20 Series, 3dr SUV Jun 00-Jan 06 AU 75 80

First Time Installation



- Remove parts from inside the package and check. Contact your dealer if any parts are missing or damaged.



- This kit fits type A, B, C and D.
- These instructions show type A crossbar fitted. They also apply to type B, C and D.




- Use keys to remove covers.



- Use hex screwdriver to reverse adjusting screw 10 turns.




- Press adjusting screw and pull crossbar legs out. Refer to the crossbar instructions for crossbar adjustment.
- Ensure each end of the crossbar is adjusted equally.



- Adjust crossbar in or out to suit vehicle. Refer to the crossbar instructions for crossbar adjustment.
- Ensure that the crossbar is adjusted evenly at both ends.
- Please check the rear of this manual for information relating specifically to your vehicle.



- Tighten adjusting screw to 5 Nm (3.7 ft lb).



- Remove plastic clamp block by gripping bar leg with fingers and push firmly with thumbs until clamp block drops out behind leg.




- Select plastic internal block (from fitting kit) and insert into foot.
- Repeat for all legs.




- Fit rubber pad (supplied with crossbar) to foot.
- Make sure the pad fits into the holes underneath the foot.
- Repeat for all legs.

Fitment



- Open or remove fixed-point covers.
- Fixed point may vary to those pictured.



- Hook clamps into the fixed points on the vehicle.



- Ensure internal clamp sits upright.
- Repeat for all four positions.



- Place ditch mould insert over the clamp.



- Mount crossbars over clamps.



- Tighten the red plastic knob. The side with the nut showing should be facing up.



- Ensure the red plastic knob is in the position shown when fully tightened.
- Repeat for all legs.



- Check crossbar is securely attached to the vehicle.
- Use keys to fit and lock covers

CAUTION:

Recheck all fasteners immediately after a load is applied to the crossbars.

Regularly check screws are tight.





Maintenance

- Clean the car roof and surfaces of the product that will be in contact with the car roof.
- Follow the fitting instructions for fitting the product to your vehicle. Make sure all steps are carried out in order.
- Set crossbars a minimum distance of 700mm (27 1/2") apart where no other distance is specified in the fitting instructions. This is especially important when carrying long loads.
- Check unit is securely attached whenever you refit it to the vehicle. If the unit feels loose, refer to the fitting instructions and readjust.
- Some glass/panoramic roofs and radio antennae may not be able to be used when the product is fitted.
- Do not modify this product.
- Refer to the maximum permitted load capacity specified in the fitting instructions. Do not exceed the vehicle manufacturers roof load rating if it is lower than the maximum load capacity specified in the fitting instructions.
- Refer to the maximum permitted load capacity specified in the fitting instructions. Do not exceed the vehicle manufacturers roof load rating if it is lower than the maximum load capacity specified in the fitting instructions.
- Long loads should be secured with non-elastic straps to the front and rear of the vehicle.
- Objects with pointed ends (e.g. ski poles) should be carried with the pointed ends to the rear of the vehicle.
- Remove all loose or removable objects from the load prior to loading.

- Make sure all loads are securely fastened with non-elastic straps. Check regularly during longer journeys.
- A loaded roof rack system can alter the performance of your vehicle. Be especially aware of the effects of side winds, changing of direction, and braking performance. Avoid rapid acceleration and deceleration. Drive carefully.
- Note that the total height of the vehicle increases when upright loads are carried.
- Products should be locked during transport if they have locks fitted.
- Check and replace worn out or defective parts.
- Keep the product clean and maintained.
- Never drive into a car wash with the roof rack system fitted.
- Lubricate locks and adjusting screws at regular intervals.
- Remove the products from the vehicle when not in use. Make sure all loose parts are stored safely.

- Hubco Automotive Ltd
P. O. Box 11017
Christchurch
NEW ZEALAND

www.whispbar.com
www.whispbar.com.au
www.whispbar.co.nz
www.whispbar.co.uk
www.whispbar.co.za
www.whispbar.eu
www.whispbar.ca



Lexus LX470 , 5dr SUV Apr 98-Jul 07 (AU)

Lexus LX470 , 5dr SUV May 98-Oct 07 (NZ)

Suzuki SX4 , 5dr Hatch 06-+ (EU)

Suzuki SX4 , 5dr Hatch 06-+ (ZA)

Suzuki SX4 , 5dr Hatch Mar 07-+ (AU)

Suzuki SX4 , 5dr Hatch Mar 07-+ (NZ)

Suzuki SX4 Sportback, 5dr Hatch 07-+ (US)

Toyota Land Cruiser 100 Series, 5dr SUV 98- 07 (EU)

Toyota Land Cruiser 100 Series, 5dr SUV 98- 07 (US)

Toyota Land Cruiser 100 Series, 5dr SUV 98- 07 (ZA)

Toyota Land Cruiser 100 Series, 5dr SUV Apr 98-Jun 07 (AU)

Toyota Land Cruiser 100 Series, 5dr SUV Apr 98-Oct 07 (NZ)

Toyota Land Cruiser 200 Series, 5dr SUV 07-+ (EU)

Toyota Land Cruiser 200 Series, 5dr SUV 07-+ (US)

Toyota Land Cruiser 200 Series, 5dr SUV Aug 07-+ (AU)

Toyota Land Cruiser 200 Series, 5dr SUV Nov 07-+ (NZ)

Toyota Land Cruiser Prado , 5dr SUV 03- 09 (EU)

A	B	C	X		
			1	2	3
150mm	820mm	1540mm	1040mm	1010mm	980mm
5 7/8"	32 5/16ths"	60 5/8"	40 15/16ths"	39 3/4"	38 9/16ths"
150mm	820mm	1540mm	1040mm	1010mm	980mm
5 7/8"	32 5/16ths"	60 5/8"	40 15/16ths"	39 3/4"	38 9/16ths"
-120mm	600mm	-	759mm	723mm	-
-4 3/4"	23 5/8"	-	29 7/8"	28 7/16ths"	-
-120mm	600mm	-	759mm	723mm	-
-4 3/4"	23 5/8"	-	29 7/8"	28 7/16ths"	-
-120mm	600mm	-	759mm	723mm	-
-4 3/4"	23 5/8"	-	29 7/8"	28 7/16ths"	-
-120mm	600mm	-	759mm	723mm	-
-4 3/4"	23 5/8"	-	29 7/8"	28 7/16ths"	-
150mm	820mm	1540mm	1040mm	1010mm	980mm
5 7/8"	32 5/16ths"	60 5/8"	40 15/16ths"	39 3/4"	38 9/16ths"
150mm	820mm	1540mm	1040mm	1010mm	980mm
5 7/8"	32 5/16ths"	60 5/8"	40 15/16ths"	39 3/4"	38 9/16ths"
150mm	820mm	1540mm	1040mm	1010mm	980mm
5 7/8"	32 5/16ths"	60 5/8"	40 15/16ths"	39 3/4"	38 9/16ths"
150mm	820mm	1540mm	1040mm	1010mm	980mm
5 7/8"	32 5/16ths"	60 5/8"	40 15/16ths"	39 3/4"	38 9/16ths"
280mm	940mm	1600mm	983mm	954mm	935mm
11 "	37 "	63 "	38 11/16ths"	37 9/16ths"	36 13/16ths"
280mm	940mm	1600mm	983mm	954mm	935mm
11 "	37 "	63 "	38 11/16ths"	37 9/16ths"	36 13/16ths"
280mm	940mm	1600mm	983mm	954mm	935mm
11 "	37 "	63 "	38 11/16ths"	37 9/16ths"	36 13/16ths"
280mm	940mm	1600mm	983mm	954mm	935mm
11 "	37 "	63 "	38 11/16ths"	37 9/16ths"	36 13/16ths"
-	850mm	1340mm	920mm	864mm	841mm
-	33 7/16ths"	52 3/4"	36 1/4"	34 "	33 1/8"

Toyota Land Cruiser Prado , 5dr SUV Mar 03-Nov 09 (NZ)	-	850mm	1340mm	920mm	864mm	841mm
	-	33 7/16ths"	52 3/4"	36 1/4"	34 "	33 1/8"
Toyota Land Cruiser Prado 120 Series, 5dr SUV Mar 03-Oct 09 (AU)	-	850mm	1340mm	920mm	864mm	841mm
	-	33 7/16ths"	52 3/4"	36 1/4"	34 "	33 1/8"
Toyota Land Cruiser Prado GX, 5dr SUV Dec 09+ (NZ)	20mm	830mm	1310mm	935mm	895mm	875mm
	13/16ths"	32 11/16ths"	51 9/16ths"	36 13/16ths"	35 1/4"	34 7/16ths"
Toyota Land Cruiser Prado GX, 5dr SUV Nov 09+ (AU)	20mm	830mm	1310mm	935mm	895mm	875mm
	13/16ths"	32 11/16ths"	51 9/16ths"	36 13/16ths"	35 1/4"	34 7/16ths"
Toyota Rav 4 , 3dr SUV 00- 05 (ZA)	-440mm	230mm	510mm	-	-	-
	-17 5/16ths"	9 1/16ths"	20 1/16ths"	-	-	-
Toyota Rav 4 , 3dr SUV 00- 05 (ZA)	-440mm	230mm	510mm	862mm	808mm	790mm
	-17 5/16ths"	9 1/16ths"	20 1/16ths"	33 15/16ths"	31 13/16ths"	31 1/8"
Toyota Rav 4 , 3dr SUV 00- 06 (EU)	-440mm	230mm	510mm	862mm	808mm	790mm
	-17 5/16ths"	9 1/16ths"	20 1/16ths"	33 15/16ths"	31 13/16ths"	31 1/8"
Toyota Rav 4 , 3dr SUV 00- 06 (EU)	-440mm	230mm	510mm	-	-	-
	-17 5/16ths"	9 1/16ths"	20 1/16ths"	-	-	-
Toyota Rav 4 , 3dr SUV 94- 00 (EU)	-	-	-	-	-	-
	-	-	-	-	-	-
Toyota Rav 4 , 3dr SUV 94- 00 (US)	-	-	-	-	-	-
	-	-	-	-	-	-
Toyota Rav 4 , 3dr SUV 94- 99 (ZA)	-	-	-	-	-	-
	-	-	-	-	-	-
Toyota Rav 4 , 3dr SUV Jun 00-Jan 06 (NZ)	-440mm	230mm	510mm	862mm	808mm	790mm
	-17 5/16ths"	9 1/16ths"	20 1/16ths"	33 15/16ths"	31 13/16ths"	31 1/8"
Toyota Rav 4 , 3dr SUV Jun 00-Jan 06 (NZ)	-440mm	230mm	510mm	-	-	-
	-17 5/16ths"	9 1/16ths"	20 1/16ths"	-	-	-
Toyota Rav 4 , 3dr SUV Jun 94-May 00 (AU)	-	-	-	-	-	-
	-	-	-	-	-	-
Toyota Rav 4 , 3dr SUV Jun 94-May 00 (NZ)	-	-	-	-	-	-
	-	-	-	-	-	-
Toyota Rav 4 , 5dr SUV 00- 04 (EU)	-100mm	550mm	1120mm	854mm	806mm	792mm
	-3 15/16ths"	21 5/8"	44 1/8"	33 5/8"	31 3/4"	31 3/16ths"
Toyota Rav 4 , 5dr SUV 00- 06 (ZA)	-100mm	550mm	1120mm	854mm	806mm	792mm
	-3 15/16ths"	21 5/8"	44 1/8"	33 5/8"	31 3/4"	31 3/16ths"
Toyota Rav 4 , 5dr SUV 94- 00 (EU)	220mm	830mm	-	745mm	735mm	-
	8 11/16ths"	32 11/16ths"	-	29 5/16ths"	28 15/16ths"	-
Toyota Rav 4 , 5dr SUV 94- 99 (ZA)	220mm	830mm	-	745mm	735mm	-
	8 11/16ths"	32 11/16ths"	-	29 5/16ths"	28 15/16ths"	-
Toyota Rav 4 , 5dr SUV Dec 94-May 00 (NZ)	220mm	830mm	-	745mm	735mm	-
	8 11/16ths"	32 11/16ths"	-	29 5/16ths"	28 15/16ths"	-
Toyota Rav 4 , 5dr SUV Jul 95-May 00 (AU)	220mm	830mm	-	745mm	735mm	-
	8 11/16ths"	32 11/16ths"	-	29 5/16ths"	28 15/16ths"	-
Toyota Rav 4 , 5dr SUV Jun 00-Jan 06 (NZ)	-100mm	550mm	1120mm	854mm	806mm	792mm
	-3 15/16ths"	21 5/8"	44 1/8"	33 5/8"	31 3/4"	31 3/16ths"
Toyota Rav 4 20 Series, 3dr SUV Jun 00-Jan 06 (AU)	-440mm	230mm	510mm	-	-	-
	-17 5/16ths"	9 1/16ths"	20 1/16ths"	-	-	-
Toyota Rav 4 20 Series, 3dr SUV Jun 00-Jan 06 (AU)	-440mm	230mm	510mm	862mm	808mm	790mm
	-17 5/16ths"	9 1/16ths"	20 1/16ths"	33 15/16ths"	31 13/16ths"	31 1/8"
Toyota Rav 4 20 Series, 5dr SUV Jun 00-Jan 06 (AU)	-100mm	550mm	1120mm	854mm	806mm	792mm
	-3 15/16ths"	21 5/8"	44 1/8"	33 5/8"	31 3/4"	31 3/16ths"