

K409 ASSEMBLY AND FITTING INSTRUCTIONS

Kit Contains

- 1 x Instructions
- 2 x Front Clamps (labeled)
- 2 x Rear Clamps (labeled)
- 2 x Rear Pads (labeled)
- 1 x LH / Front Pad (labeled)
- 1 x RH / Rear Pad (labeled)

Remove parts from box & check
Contact your Prorack dealer if any
parts are missing or damaged

Maximum
Whispbar
Load
Rating

75
kg

When Fitted and loaded
correctly


Items you will require that are not included:

Tape measure

Important Note:

Whispbar Flush Bar pictured in these instructions, also applicable for Whispbar Through Bar

1. Crossbar Preparation




1.1



1.2

- Using tape measure identify 950mm long crossbar
- Assemble this bar with pads and clamps marked "Rear" and mount in rear position on vehicle. Use other crossbar as Front bar.
- Note: Applies to Flush Bar only. For Through Bar any crossbar can be nominated front or rear.
- Pad part numbers could be found on the underside of the pad along with position labels.



1.3

- Letters refer to the pad part numbers

Refers to Pad 11-04-250

Refers to Pad 11-04-251

Refers to Pad 11-04-244



1.4

- Fit stepped rubber pad (from fitting kit) to foot.
- Press pad firmly onto foot by putting thumb pressure on area where pad spigots engage.
- The pad shape may vary from the photo.

2. Positioning Crossbar on Vehicle



2.1

- Locate the bars on the vehicle as indicated on the photo.
- Remove clamp screws (Refer to crossbar instructions for details).
- Fit 556 clamps labeled "Front" to nominated front bars and 557 clamps labeled "Rear" to nominated rear bars.
- Clamps directly to edge of roof under the doors.
- Replace clamp screws.
- Progressively tighten the screws. Alternate from side to side to tension evenly.



2.2

- Check that crossbar feels tight on the roof.
- Refit covers to leg.

Warning Notes:

Use these instructions in conjunction with crossbar instructions

WARNING: Check the Tightness of Screws Regularly